

Compressor Model Number Significance

06D Compressors

06D* 3 37 0 D A 36 0 0

Model = 0, Package = 1 or 9, A= shipped without oil

Suction Cut Off Unloading
 Designation for 06DR/DM New Compressors
 0 = All Models Except as Noted
 4 = 1 Unloader Electric SCO (DR/DM Only)
 5 = NO OIL
 6 = 1 Unloader Pressure (DR/DM Only)

Electrical Characteristics XL start only, unless noted

New H.E. Models	Old Standard Models
31 = 575 - 3 - 60	01 = 575 - 3 - 60
32 = 208/230 - 3 - 60	04 = 200 - 3 - 60
33 = 208/230 - 1 - 60	05 = 230 - 3 - 60
34 = 220 - 3 - 50	06 = 400/460 - 3 - 50/60
36 = 400/460 - 3 - 50/60	08 = 220 - 3 - 50
	12 = 208/230 - 3 - 60
	13 = 380 - 3 - 60
	14 = 200 - 3 - 60 (PW)
	15 = 230 - 3 - 60 (PW)
	18 = 220 - 3 - 50 (PW)

Electrical Variables
 A = W/Internal Thermostat & W/External Overloads
 C = W/Internal Thermostat & W/O External Overloads
 T = Service Compressor (Tecumseh)

Suction Valve Variables:
 Location, Orientation & Mounting Bolts

Compressor Identification Key:
 0 = New Compressor, DR/DM (OEM) Or A/C (Carrier)
 2 = New Compressor, A/C (OEM) or A/C (Carrier)
 3 = New Compressor, Tyler (Carrier)
 4 = New Compressor, Tecumseh
 6 = Service Compressor, Remanufactured
 7 = Service Compressor, New Manufactured
 8 = New Compressor, Special
 9 = Service Compressor, Special

Displacement In CFM

Motor Size - No Significance

Compressor Type		
06DA = New Compressor, A/C Duty	No Unloading	
06DB = New Compressor, A/C Duty	1 Step Elec.	HGBP
06DC = New Compressor, A/C Duty	2 Step Elec.	HGBP
06DD = New Compressor, A/C Duty	1 Step Pres.	HGBP
06DE = New Compressor, A/C Duty	2 Step Pres.	HGBP
06DF = New Compressor, A/C Duty	1 Step Elec.	SCO
06DG = New Compressor, A/C Duty	2 Step Elec.	SCO
06DH = New Compressor, A/C Duty	1 Step Pres.	SCO
06DJ = New Compressor, A/C Duty	2 Step Pres.	SCO
06DM = New Compressor, Refr. Duty Med Temp		
06DM = Service Compressor - Replaces 06DA/DM No unl.		
06DR = New Compressor, Refr. Duty Low Temp		
06DS = Service Compressor - Replace 06DF, G, H & J w/unl..		
06DX = Service Compressor - Replace 06DB, C, D & E w/unl		
06DN = 2 Shaved Heads, Special Order		
06DW = A/C 2 Plugged Hds, Replaces All C&E Service Spec. Orders		
06DY = Refr. 2 Plugged Hds, Service Special Order		